

## P1A-S pendant PathPilot driver Installation

1. Reboot and when you see the "TORMACH" splash screen, hold down the left SHIFT and ALT keys to boot to desktop.

2. Copy and move following files to PathPilot PC under /home/operator

```
Makefile
vc-plas
vc-plas-pp.hal
99-vistacnc-pendant.rules
```

3. Double click **Makefile**, select **Run**. This will install vc-plas to /usr/bin and 99-vistacnc-pendant.rules to /lib/udev/rules.d

4. Copy and move **vc-plas-pp.hal** to **/home/operator/tmc/configs/tormach\_mill** directory

5. Open and add following lines (**in bold font**) to **tormach\_1100-3.ini** files (in **/home/operator/tmc/configs/tormach\_mill** directory):

```
[HAL]
HALFILE = my-mill.hal
HALFILE = custom.hal
HALFILE = vc-plas-pp.hal
POSTGUI_HALFILE = custom_postgui.hal
HALUI = halui
```

6. The number of decimal digit to display and step size selections are defined in **vc-plas-pp.hal**.

Open and edit **vc-plas-pp.hal** file.

```
.
.
#P1A-S pendant settings
#number of decimal digit to display on axis DRO,
#settable number:2,3,4
setp vc-plas.decimal 3

#step size, set 0 to skip.
setp vc-plas.stepsize-1 0.0001
setp vc-plas.stepsize-2 0.001
setp vc-plas.stepsize-3 0.01
setp vc-plas.stepsize-4 0.1
setp vc-plas.stepsize-5 1
setp vc-plas.stepsize-6 10
setp vc-plas.stepsize-7 0
setp vc-plas.stepsize-8 0
setp vc-plas.stepsize-9 0
```